

Toner model kodu	Printer Model	sayfa sayısı
<b>CE255A</b>	HP LaserJet P3010/3015/3015d/3015dn/3015x	6000
<b>CE255X</b>	HP LaserJet P3015/3015d/3015dn/3015x	12500
<b>CC364A</b>	HP LaserJet P4014/4014n/P4015/4015n/4015tn/P4515/4515n/4515tn/4515x/4515fx	10000
<b>CC364X</b>	HP LaserJet P4015/4015n/4015tn/P4515/4515n/4515tn/4515x/4515fx	24000
<b>CE505A</b>	HP LaserJet P2030/2035/2035n/2050/2055d/2055dn/2055x	2300
<b>CE505X</b>	HP LaserJet P2050/2055d/2055dn/2055x	6500
<b>CB435A</b>	HP P1005/P1006	1500
<b>CB436A</b>	HP P1500/P1505/P1505N/1522/M1120/M1120N/M1522N/M1522F	2000
<b>CF283A</b>	HP Laserjet M125/M126/M127F/201/225	1600
<b>CF283X-CRG137/337/737</b>	HP laserJet ProM202dw/M225dn/dw/rdn/ M202n/M201dw/n/M226dn/dw Canon i-SENSYS MF217w/MF211/MF212W/MF216N/MF226dw/MF227DW/MF229DW/MF224dw/MF222dw	2200
<b>CC388A</b>	HP P1007/1008	2000
<b>CB435/CB436/285A universal</b>	HP P1005/P1006/P1500/P1505/1522/M1120/M1120N/M1522N/M1522F/P1505N/P1102/P1102W	2000
<b>CE278A</b>	HP laser Pro P1560/1636/1566/1600/1606	2100
<b>CE285A</b>	HPLaserJet P1100/P1102/P1102W/P1104/P1104W/P1106/P1106W/P1107/P1107W/P1108/P1108W/P1109/P1109 / M1132/M1210/M1212nf/M1214nf/M1216nf/M1217nf w/M1218nf/M1219nf	1600
<b>CB435/CB436/CE285 universal</b>	HPP1005/P1006/1500/P1505/1522/M1120/M1120N/M1522N/M1522F/P1100/P1102/P1102W/P1104/P1104W/P1106/P1106W/P1107/P1107W/P1108/P1108W/P1109/P1109/M1132/M1210/M1212nf/M1214nf/M1216nf/M1217nf/M1218nf/M1219nf	2000
<b>CF280A OEM</b>	HP Laser Pro 400/M401/a/d/n/dn/dw/M425dn/425dw	2700
<b>CF280X OEM</b>	HP Laser Pro 400/M401/a/d/n/dn/dw/M425dn/425dw	6900
<b>CE390A</b>	HP LaserJet M4555MFP/M601/M601n/M602n/M602dn/M602x/M603/M603n/M603dn/M603xh	10000
<b>CE390X</b>	HP LaserJet M4555MFP/M601/M601n/M602n/M602dn/M602x/M603/M603n/M603dn/M603xh	24000
<b>Q7570A</b>	HP LaserJet M5025/M5035 /M5035x/M5035xs	15000
<b>C8543X</b>	HP LaserJet 9000/9000n/9000dn/9000hns/9000hnf/9040/9040n/9040dn/9050/9050dn	30000
<b>Q6511A</b>	HP LaserJet 2410/2410n/2420/2420n/2420d/2420dn/2430/2430n/2430t/2430tn	6000
<b>Q6511X</b>	HP LaserJet 2410/2410n/2420/2420n/2420d/2420dn/2430/2430n/2430t/2430tn	12000
<b>Q5949A</b>	HP Laser jet 1160/1320/1320n/1320t/1320tn	2500
<b>Q5949X</b>	HP Laser jet 1320/1320n/1320t/1320tn	6000
<b>Q5949A/7553A</b>	HP Laser jet 1160/1320 /3390/3392;HP LaserJet P2010/P2015/P2014/M2727nf MFP	3000
<b>Q5949X/7553X</b>	HP Laser jet 1160/1320 /3390/3392;HP LaserJet P2010/P2015/P2014/M2727nf MFP	6000
<b>CZ192</b>	HPM435/435NW	12000
<b>Q7516A</b>	HP5200/5200n/5200tn/5200dtn	12000
<b>CF214A</b>	LJ Enterprise 700 M712n/dn/M725	10000
<b>CF214X</b>	LJ Enterprise 700 M712n/dn/M725	17500
<b>Q7551A</b>	HP LaserJet P3005/P3005d/P3005n/P3005dn/P3004/P3004N/P3004D/3004DN/M3027/M3035	6000
<b>Q7551X</b>	HP LaserJet P3005/P3005d/P3005n/P3005dn/P3004/P3004N/P3004D/3004DN/M3027/M3035	13000

Q7553A	HP LaserJet P2011/P2012/P2013/P2014/P2015/P2015d/P2015n/P 2015dn/M2717	3000
Q7553X		6000
Q2612A	HP Laser jet 1010/1012/1015/3015/3020/3030/1319/3050/3052/30 55	2000
Q2612A/FAX-9/-10	HP Laser jet 1010/1012/1015/3015/3020/3030/1319/3050/3052/30 55	2000
Q2612X	HP Laser jet 1010/1012/1015/3015/3020/3030/1319/3050/3052/30 55	3000
Q2613A	HP Laser jet 1300/1300N/1300XI	2500
Q2613X		4000
Q2624A	HP Laser jet 1150/1150N	2500
Q2624X		4000
Q7115A	HP Laser jet	2500
Q7115X	1000/1200/1220/3300/3310/3320/3330 /3380	3500
Q7115A/2613A/2624A	HP Laser jet 1300/1300N/1300XI,HP Laser jet 1150/1150N;HP Laser jet 1000/1200/1220/3300/3310/3320/3330 / 3380/1000W/1005W/1220	2500
Q7115X/2613X/2624X	HP Laser jet 1300/1300N/1300XI,HP Laser jet 1150/1150N;HP Laser jet 1000/1200/1220/3300/3310/3320/3330 / 3380/1000W/1005W/1220	3500
C3906F/FX3	HP5L/6L/3100/3150	2500
C4092A	HP1100/3200	2500
C4096A	HP Laser jet 2100/2200/2100M/2100TN	5000
C4127A	HP4000/4000T/4000N/4050	6000
C4127X	HP4000/4000T/4000N/4050	10000
C4129X	HP5000/5000DN/5000GN/5000LE/5100/5100TV/5100 DTN/5100L	10000
Q2610A	HP2300/2300L	6000
C8061A	HP4100/4100N/4100TN/4100DTN/4100MFP	6000
C8061X	HP4100/4100N/4100TN/4100DTN/4100MMFP	10000
92298A	HP4/4+/5/5M	6700
C3909A	HP8000/5SI/MOPIER240	15000
C4182X	HP8100/8150/8150DN/8150HN/MOPIER320	20000
C3900A	HP4V/4VC/4MV	8000
Q1338A/1339A/5942A/5942X/5945A	HP LaserJET 4200/4300/4240/4240N/4250/4350/4345Series	12000
Q1338A/1339A/5942A/5942X/5945A	HP LaserJET 4200/4300/4240/4240N/4250/4350/4345Series	18000
Q1338A/1339A/5942A/5942X/5945A	HP LaserJET 4200/4300/4240/4240N/4250/4350/4345Series	20000
92274A	HP4L/4ML/4P/4MP	3000
C3903F	HP5P/5MP/6P/6MP	4000
CF210A	HP Laser Jet Pro 200/color M251nw/color M251n/color MFP M276n/color MFP M276nw	1600
CF210X		2400
CF211A		1800
CF212A		1800
CF213A		1800
CF380A		2400
CF380X	HP MFP M476DW/476DN/476NW	4400
CF381A		2700
CF382A		2700
CF383A		2700
CE400A		5500
CE400X	HP M551/M551dn/M551n/M551xh/500	11000
CE401A		6000
CE402A		6000
CE403A		6000
CE410A		2200

CE410X	HP M451dn/M451nw,HP M375nw/M475dn	4000
CE411A		2600
CE412A		2600
CE413A		2600
CE270A	HP CP5525/5525N/5525dn/5525sh	13500
CE271A		15000
CE272A		15000
CE273A		15000
CE740A	HP CP5225/5225N/5225DN	7000
CE741A		7300
CE742A		7300
CE743A		7300
CE310A	HP laserjet Pro CP1025NW	1200
CE311A		1000
CE312A		1000
CE313A		1000
CE314A Drum Unit		14000
CF350A	HP Laserjet Pro MFP M176/M177	1300
CF351A		1000
CF352A		1000
CF353A		1000
CE320A	HP laserjet Pro CM1415FN/1415FNW	2000
CE321A		1300
CE322A		1300
CE323A		1300
CE260A	HP4525N/4525DN	8000
CE261A		11000
CE262A		11000
CE263A		11000
CE260X	HP4525N/4525DN	17000
CB400A	HP Color LaserJet CP4005	7500
CB401A		7500
CB402A		7500
CB403A		7500
CE250A	HP4525N/4525DN	5000
CE250X		10000
CE251A		7000
CE252A		7000
CE253A		7000
Q7560A	HP3000	6500
Q7561A		3500
Q7562A		3500
Q7563A		3500
Q3960A	HP2550	4000
Q3961A		4000
Q3962A		4000
Q3963A		4000
Q3964A Drum unit	HP2550	20000
C9700A	HP1500/2500	4000
C9701A		4000
C9702A		4000
C9703A		4000

C9720A	HP4600	8000
C9721A		8000
C9722A		8000
C9723A		8000
C9730A	HP5500	12000
C9731A		12000
C9732A		12000
C9733A		12000
Q6000A	HP2600	2500
Q6001A		2000
Q6002A		2000
Q6003A		2000
Q2670A	HP3500/3500N	6000
Q2671A		4000
Q2672A		4000
Q2673A		4000
Q2680A	HP3700	6000
Q2681A		6000
Q2682A		6000
Q2683A		6000
CB540A	HP1215/1515/1518/CM1312	2300
CB541A		1500
CB542A		1500
CB543A		1500
CC530A	HPCP2020/2025/CM2320	3500
CC531A		2800
CC532A		2800
CC533A		2800
Q6470A	HP3600	6000
Q6471A		4000
Q6472A		4000
Q6473A		4000
Q7580A	HP3800	6000
Q7581A		6000
Q7582A		6000
Q7583A		6000
Q5950A	HP4700	10000
Q5951A		10000
Q5952A		10000
Q5953A		10000
<b>FOR USE IN CANON</b>		
FAX-1	CANON L700/760/770/775/777	3500
FAX-2	CANON L500/550/600	3000
FAX-3	CANON L200/240/250/260i/280/290/300/350/360	2500
FAX-3 /3906	CANON L200/240/250/260i/280/290/300/350/360	2500
FAX-4	CANON L800/900	4000
FAX-7		5000
CRG337/137/737/283X	Canon ImageCLASS MF211/212W/215/216N/217W/221D/223D/226DN/227DW/229DW Canon i-SENSYS MF211/212w/216n/217w/226dn/229dw	2400

<b>CRG120/CRG720</b>	Canon D1120 /MF6880	5000
<b>FX-9/FX-10/Canon 104</b>	CANON L100/MF4150	2000
<b>EP-22</b>	CANON LBP800/810/1120	2500
<b>EP-26/E27/X25</b>	CANON LBP-3200/D3112/5630/5650; LASER SHOT MF3100series; IMAGECLASS MF-3100/5530/5550/5730/5770/MF5630/MF5650; Image Class MF5500 Series; Image Class MF3110	2500
<b>E-30/40</b>	CANON FC-210/230/310	4000
<b>EP-U</b>	CANON MF3112/3220/3222/5630/	2500
<b>EP-W</b>	CANON D323/383	2500
<b>EP-T</b>	CANON L380/400/PCD320	3500
<b>EP-N/L50</b>	CANON D620/660/760/PC1210	5000
<b>CRG-106/306/706</b>	CANON 106/Canon MF6530 Image Class Duplex Copier	5000
<b>EP-25/FX8/CRG-W/T/S35</b>	CANON LBP-1210, D323/383/L398/390, IMAGECLASS D320/D323/D340/D383 FAX-L170	3500
<b>CRG303/703</b>	CANON LBP2900/3000	2000
<b>CRG-308/508/708</b>	Canon LBP 3300/3360	2500
<b>CRG-308 II/508 II/708 II</b>	Canon LBP 3300/3360	6000
<b>CRG312/712/912</b>	CANON LBP3018/LBP3100/3010/3050	2000
<b>CRG313/713</b>	Canon 3250	2000
<b>CRG315</b>	CANON LBP3310	3000
<b>CRG315II</b>	CANON LBP3310	6000
<b>CRG-110/310/510/710</b>	Canon LBP 3410/3460	6000
<b>CRG-110 II/310 II/510 II/710 II</b>	Canon LBP 3410/3460	12000
<b>CRG-309/509</b>	Canon LBP3980/3970/3950/3930/3920/3910/3900/3500	12000
<b>CRG-527</b>	Canon LBP8610/8620/8630	15000
<b>CRG-119/319/519/719</b>	Canon LBP 6300/6650/imageCLASS MF5850dn/5880dn	2100
<b>CRG-119II/319II/519 II/719II</b>	Canon LBP 6300/6650/imageCLASS MF5850dn/5880dn	6400
<b>CRG 125/725</b>	Canon imageCLASS LBP6000	1600
<b>CRG 128/728</b>	Canon imageCLASS MF4570dn	2100
<b>CRG101/301/701 BK</b>		5000
<b>CRG101/301/701 Y</b>	Canon LBP-2410/MF8150C/8170C/8180C/5200	4000
<b>CRG101/301/701 M</b>		4000
<b>CRG101/301/701 C</b>		4000
<b>CRG-323BK</b>		5000
<b>CRG-323 II BK</b>		10000
<b>CRG-323YEL</b>	Canon LBP 7700C/7750Cdn	8500
<b>CRG-323MAG</b>		8500
<b>CRG-323CYN</b>		8500
<b>CRG118/318/418/718 BK</b>		3400
<b>CRG118/318/418/718 C</b>		2900
<b>CRG118/318/418/718 Y</b>	Canon LBP 7200/7200cn/iC MF8330/8350Cdn	2900
<b>CRT118/318/418/718 M</b>		2900
<b>CRG116/316/416/716BK</b>		2300
<b>CRG116/316/416/716C</b>		1500
<b>CRG116/316/416/716Y</b>	CANON LBP5050/5050N	1500
<b>CRG116/316/416/716M</b>		1500
<b>CRG303/707BK</b>		2500
<b>CRG303/707C</b>		2000
<b>CRG303/707Y</b>	CANON LBP5000	2000
<b>CRG303/707M</b>		2000
<b>CRG-111/311/711BK</b>		6000
<b>CRG-111/311/711C</b>	Canon LBP 5300/5360/5400/C1022 color imageCLASS	6000
<b>CRG-111/311/711Y</b>	MF9130/9150c/9170c/9280Cdn/9220Cdn/HP3500	6000

<b>CRG-111/311/711M</b>		6000
<b>FOR UNS IN SAMSUNG</b>		
<b>MLT-D101</b>	SAMSUNG ML2165W/SCX-3405W	1500
<b>MLT-D103S</b>	SAMSUNG ML-2545/2950ND	1500
<b>MLT-D103L</b>	SAMSUNG ML-2545/2950ND	2500
<b>MLT-D106</b>	SAMSUNG ML-2245	2000
<b>MLT-D106 Drum</b>	SAMSUNG ML2245	12000
<b>MLT-D104S</b>	SAMSUNG ML-1660/1661/1665/1666	1500
<b>MLT-D105S</b>	SAMSUNG ML1900/1910/1911/1915/2580/SF650P/SCX4600	1500
<b>MLT-D105L</b>	SAMSUNG ML1900/1910/1911/1915/2580/SF650P/SCX4600	2500
<b>MLT-D108S</b>	SAMSUNG ML1640/2240	1500
<b>MLT-D109S</b>	SAMSUNG SCX4300	2000
<b>MLT-208S</b>	SAMSUNG ML-1635/3475/SCX5635	4000
<b>MLT-208L</b>	SAMSUNG ML-1635/3475/SCX5635	8000
<b>MLT-D209S</b>	SAMSUNG SCX4824FN/4828FN	2000
<b>MLT-D209L</b>	SAMSUNG SCX4824FN/4828FN	5000
<b>SCX6320D8 toner unit</b>	SAMSUNG SCX-6120/6220/6320/6322/6520	8000
<b>SCX6320R2 drum unit</b>	SAMSUNG SCX-6120/6220/6320/6322/6520	20000
<b>ML-D3470A</b>	SAM ML3470/3470D/3471/3471ND	4000
<b>ML-D3470B</b>	SAM ML3470/3470D/3471/3471ND	10000
<b>ML-D2850A</b>	Samsung ML2450/2850/2851	2000
<b>ML-D2850B</b>	Samsung ML2450/2850/2851	5000
<b>ML-1710/4100/SCX4216 universal</b>	SMSUNG ML-1510/1520/1710/1740/1745/1750  SAMSUNG SCX4016/4100/4116/4216/4216F  SF560/565P/750/755P  MSYS 750/755P  Gestener DSM516PF  Xerox 3130/3120/3115/3121/PE16  Lexmark X215  Savin AC104  Ricoh AC104	3000
<b>ML-1610/2010/SCX4521 universal</b>	SAMSUNG ML-1610/2010/2510/2570/2570N/2571  SAMSUNG SCX-4521F  Xerox Phaser-3117/3122/3124/3125	3000
<b>ML-1210/5100 /4500 universal</b>	SAMSUNG ML1210/1010/1020M/1220M/1250/1430/SF550/ Lexmark Ora E210/Xerox Phaser 3110/3210 SAMSUNG SF-515/530/531P/535E SAMSUNG SF5100/5100P/MSY5100P/SAMSUNG ML- 808/SAMSUNG ML-4500/4600	3000
<b>SF-560R</b>	SAMSUNG SF560R	3000
<b>ML-D3050A</b>	SAMSUNG ML3050/3051	4000
<b>ML-D3050B</b>	SAMSUNG ML3050/3051	8000
<b>SCX-D5530A</b>	Samsung SCX-5350/5530FN	4000
<b>SCX-D5530B</b>	Samsung SCX-5350/5530FN	8000
<b>ML-D1630A</b>	SAMSUNG ML1630 / SCX4500	2000
<b>ML-3560D6</b>	Samsung ML3560/3561/3561N	6000
<b>ML-3560DB</b>	Samsung ML3560/3561/3561N	12000
<b>ML-2250D5</b>	Samsung ML2250/2251N/2251NP/2252W	5000
<b>SCX-4521D3</b>	SAMSUNG SCX-4521/4321	3000
<b>ML-2150D8</b>	SAMSUNG ML2150	8000

<b>ML2550</b>	SAMSUNG ML-2550/2551N	10000
<b>SCX-4720/SCX-4520</b>	SAMSUNG SCX4720/SCX4520	5000
<b>SCX-4725</b>	SAMSUNG SCX-4725	3000
<b>SCX-D4200A</b>	SAMSUNG SCX4200	3000
<b>ML-D4550A</b>	Samsung ML4050/4550/4551N	12000
<b>ML-D4550B</b>	Samsung ML4050/4550/4551N	20000
<b>ML5800</b>	SAMSUNG ML5800	6000
<b>MLT-D205S</b>	SAMSUNG ML-3310D/3310ND/3312ND/SCX-5637HR	2000
<b>MLT-D205L</b>	SAMSUNG ML-3310D/3310ND/3312ND/SCX-5637HR	5000
<b>MLT-D205E</b>	SAMSUNG ML-3710D/3710DN/3712ND/3712DW//SCX-5737FW	10000
<b>MLT-D305S</b>	SAMSUNG ML-3750D/3750DN	7000
<b>MLT-D305L</b>	SAMSUNG ML-3750D/3750DN	15000
<b>MLT-D307S</b>	SAMSUNG ML-4510ND/5010ND/5015ND	7000
<b>MLT-D307L</b>		15000
<b>MLT-D307E</b>	SAMSUNG ML-5010ND/5015ND	20000
<b>MLT-R307</b>	SAMSUNG ML-4510ND/5010ND/5015ND	60000
<b>MLT-D309S</b>	SAMSUNG ML-5510N/5510ND/5512ND/6510ND, 6512ND	10000
<b>MLT-D309L</b>	SAMSUNG ML-5510N/5510ND/5512ND/6510ND, 6512ND	30000
<b>MLT-D309E</b>	SAMSUNG ML-5510N/5510ND/5512ND/6510ND, 6512ND	40000
<b>MLT-R309</b>	SAMSUNG ML-5510N/5510ND/5512ND/6510ND, 6512ND	80000
<b>MLT-D111S</b>	Samsung M2020/2020W/2022W/2070W	1000
<b>MLT-D203S</b>	SAMSUNG SL-M3320/3820/4020,M3370/3870/4070	3000
<b>MLT-D203L</b>		5000
<b>MLT-D203E</b>	SAMSUNG SL-M3820/4020,M3870/4070	10000
<b>MLT-D203U</b>	SAMSUNG SL-M3820/4020,M3870/4070	15000
<b>MLT-D204S</b>	SAMSUNG SL-M3325/3825/4025,M3375/3875/4075	3000
<b>MLT-D204L</b>		5000
<b>MLT-D204E</b>	SAMSUNG SL-M3825/4025,M3875/4075	10000
<b>MLT-R204 Drum nint</b>	SAMSUNG SL-M3325/3825/4025,M3375/3875/4075	30000
<b>MLT-D116S</b>	SAMSUNG SL-M2625/2626/2825/2826/2675/2676/2875/2876/2876N/2676FH/2876HN/2626D/2626ND/2875ND	1500
<b>MLT-D116L</b>		3000
<b>MLT-R116 Drum unit</b>		9000
<b>MLT-D115L</b>	SAMSUNG SL-M2620/2820,M2670/2870	3000
<b>MLT-D117S</b>	SAMSUNG SCX4650F/4650N/4652F/4655F/4655FN	2500
<b>CLT-K405S</b>	Samsung SL-C422/422W/420W/423/423W,SL-C472/472W/472FW/470W/C470FW/473/473W	1500
<b>CLT-C405S</b>		1000
<b>CLT-M405S</b>		1000
<b>CLT-Y405S</b>		1000
<b>CLT-K406S</b>	SAMSUNG CLP360/365/CLX3300/3305	1500
<b>CLT-C406S</b>		1000
<b>CLT-M406S</b>		1000
<b>CLT-Y406S</b>		1000
<b>CLT-K407S</b>	SAMSUNG CLP320/325/CLX3285	1500
<b>CLT-C407S</b>		1000
<b>CLT-M407S</b>		1000
<b>CLT-Y407S</b>		1000
<b>CLT-K407S</b>	SAMSUNG CLP320/325/CLX3285	1500
<b>CLT-C407S</b>		1000
<b>CLT-M407S</b>		1000
<b>CLT-Y407S</b>		1000
<b>CLT-K409S</b>	SAMSUNG CLP310/315	1500
<b>CLT-C409S</b>		1000
<b>CLT-M409S</b>		1000

CLT-Y409S		1000
CLT-K409S		1500
CLT-C409S	SAMSUNG CLP310/315	1000
CLT-M409S		1000
CLT-Y409S		1000
CLT-K508S		2500
CLT-C508S	SAMSUNG CLP620/670	2000
CLT-M508S		2000
CLT-Y508S		2000
CLT-K508L		5000
CLT-C508L	SAMSUNG CLP620/670	4000
CLT-M508L		4000
CLT-Y508L		4000
CLP-K660A		2500
CLP-C660A	SAMSUNG CLP610ND/660ND	2000
CLP-M660A		2000
CLP-Y660A		2000
CLP-K660A		5000
CLP-C660A	SAMSUNG CLP610ND/660ND	5000
CLP-M660A		5000
CLP-Y660A		5000
CLT-K504		1800
CLT-C504	SAMSUNG CLP410/470/475	700
CLT-M504		700
CLT-Y504		700
CLT-K504		2500
CLT-C504	SAMSUNG CLP410/470/475	1800
CLT-M504		1800
CLT-Y504		1800
CLT-K506		2000
CLT-C506	SAMSUNG CLP680	1500
CLT-M506		1500
CLT-Y506		1500
CLT-K506		6000
CLT-C506	SAMSUNG CLP680	3500
CLT-M506		3500
CLT-Y506		3500
CLP-K600A		4000
CLP-C600A	SAMSUNG CLP600	4000
CLP-M600A		4000
CLP-Y600A		4000
CLP-300Bk		2000
CLP-300C	SAMSUNG CLP-300	1000
CLP-300Y		1000
CLP-300M		1000
CLP-350Bk		4000
CLP-350C	SAMSUNG CLP-350	2000
CLP-350Y		2000



CLP-350M		2000
CLP-500Bk		7000
CLP-500C	SAMSUNG CLP-500/550	5000
CLP-500Y		5000
CLP-500M		5000
CLP-510Bk		7000
CLP-510C	SAMSUNG CLP-510	5000
CLP-510Y		5000
CLP-510M		5000
<b>FOR UES IN EPSON</b>		
SO50010	EPSON5700/5800 toner unit	6000
SO51055 Drum	EPSON5700/5800 drum unit	20000
SO50087	EPSON5900/6100 toner unit	6000
SO51055 Drum	EPSON5900/6100 drum unit	20000
SO50166	EPSON6200 toner unit	6000
SO50167	EPSON6200 toner unit	3000
SO51099 Drum	EPSON6200 drum unit	20000
M1200	EPSON M1200	3200
M1400	EPSON M1400	2200
M2000	EPSON M2000	3500
M2000	EPSON M2000	8000
M2300/2400	EPSON M2300/2400	3000
M2300/2400	EPSON M2300/2400	8000
C13S050690	EPSON AL-M300D/AL-M300DN	2700
C13S050689		10000
C13S050697	EPSON Workforce AL-M400	23700
C13S050698		12000
C13S050709/M200	EPSON Workforce AL-M200 DN/200DW	2500
S050226	Epson AcuLaser C2600/C2600N/ C2600DNT/C2600DN	5000
S050227		5000
S050228		5000
S050229		5000
S050097	EPSON AcuLaser C1900/C900	4500
S050098		4500
S050099		4500
S050100		4500
S050191	EPSON AcuLaser C1100	1500
S050192		1500
S050193		1500
S050190		1500
S050187		4000
S050188		4000
S050189		4000
S050190		4000
C13S050557	EPSON C1600	2500
C13S050556		2500
C13S050555		2500
C13S050554		2500
S051161	Epson C2800	8000
S051160		6000
S051159		6000
S051158		6000
S051127		9000

S051126	Epson C3800	9000
S051125		9000
S051124		9000
<b>FOR UES IN MINOLTA</b>		
K1710517-005	KONICA-MINOLTA-QMS MagiColor 2300DL/2300W/2350EN	4500
Y1710517-006		4500
M1710517-007		4500
C1710517-008		4500
K1710587-004	KONICA-MINOLTA-QMS 2400W/2430DL/2450	4500
Y1710587-005		4500
M1710587-006		4500
C1710587-007		4500
QMS 1600W A0V301F	MINOLTA 1600W	2500
QMS1600 W A0V306F		2500
QMS1600W A0V30CF		2500
QMS 1600W A0V30HF		2500
MINOLTA1300W	MINOLTA 1300W	6000
MINOLTA1300W	MINOLTA 1300W	6000
<b>FOR USE IN BROTHER</b>		
TN-420/2210/2010	Brother HL2230/2240/2270	1200
TN-450/2220	Brother HL2230/2240/2270	2600
TN720/3330	Brother HL5440D/5450D/5470D/5470DWT/6180DW/6180DW T/MFC8710DW/MFC8790DW	3000
TN750/3380	Brother HL5440D/5450D/5470D/5470DWT/6180DW/6180DW T/MFC8710DW/MFC8790DW	8000
TN780/3390	Brother HL5440D/5450D/5470D/5470DWT/6180DW/6180DW T/MFC8710DW/MFC8790DW	12000
TN-2000/2025/2050/350	BROTHER HL2040/2070N/MFC7220/7420/FAX2820/DCP7010/7 025	2500
TN-360/330/2115/2120/ 2125/2130	BROTHER HL2140/2150/2170	2600
TN-430/6300/6350/460/6600	HL1030/1230/1240/1250/1270N/1435/1430/1440/145 0/1470N; DCP1200/1400; INTELLIFAX4100/4750/14750E/5750/5750E;  MFC8300/8500/8600/8700/9600/9700/9800/P2500/96 50/9870/9660/9750/9850/9880/9860/9760; FAX8350/8370/8750	6000
TN-530/540/560/570/3030/3060/7300/7600	BROTHER HL1650/1650N/1650NPlus/1670N/1850/1870N/5040/ 5050/5050LT/5070N/5140/5150D/5150DLT/5170DN; DCP8040/8045D/8020/8025D; MFC8420/8820D/8820DNS/8220/8440/8640D/8840D/ 8840DN	6000
TN3230/620/43J	BROTHER HL5340D/5350DN/5370DW/5380DN; DCP-8070D/8080/8085DN; MFC- 8370DN/8380DN/8480DN/8880DN/8890D	3000
TN3280/650/48J	BROTHER HL5340D/5350DN/5370DW/5380DN; DCP-8070D/8080/8085DN; MFC- 8370DN/8380DN/8480DN/8880DN/8890D	8000
TN-670/4100	BROTHER HL6050/6050D/6050N	7500
TN-550/580/3130/3135 /3145/3170/3175 / 3185	BROTHER HL 5240/5250DN/5250DNT/5270/5280DW; MFC8460N/8860DN; DCP8060	7000
TN-8000/8050/200/250	BROTHER FAX8070/MFC/9030//9070/9160/9180 BROTHER FAX8060/9050 BROTHER FAX8060/9050	2200
TN630/2310/2312/2315/2330/2335/2360	Brother HL- L2300/L2305/L2320D/L2340D/L2360DN/L2360DW/L2 365DW/2380DW DCP- L2500D/L2520DW/L2540DN/L2540DW/L2560DW MFC-L2700DW/L2720DW/L2740DW	1200

<b>TN660/2320/2345/2350/2375/2380</b>	Brother HL- L2300/L2305/L2320D/L2340D/L2360DN/L2360DW/L2 365DW/2380DW DCP- L2500D/L2520DW/L2540DN/L2540DW/L2560DW MFC-L2700DW/L2720DW/L2740DW	2600
<b>DR630/2300/2355/2325</b>	Brother HL- L2300/L2305/L2320D/L2340D/L2360DN/L2360DW/L2 365DW/2380DW DCP- L2500D/L2520DW/L2540DN/L2540DW/L2560DW MFC-L2700DW/L2720DW/L2740DW L2300/L2305/L2320D/L2340D/L2360DN/L2360DW/L2 365DW/2380DW DCP- L2500D/L2520DW/L2540DN/L2540DW/L2560DW MFC-L2700DW/L2720DW/L2740DW	12000
<b>TN1020/1035/1040</b>	Brother HL-1118/DCP-1518/MFC-1813/1818	1500
<b>TN1000/1030/1050/1060/1075</b>	Brother HL-1110/DCP-1510/MFC-1810/1815	1500
<b>DR1000/1020/1030/1040/1060/1075</b>	Brother HL-1110/DCP-1510/MFC-1810/1815	10000
<b>DR-2000/2050/350</b>	BROTHER HL2040/2070N/MFC7220/7420/FAX2820/DCP7010/7 025	12000
<b>DR360/330/2115/2120 /2125/2130</b>	BROTHER HL2140/2150/2170	12000
<b>DR-520</b>	BROTHER HL5240/5250/5270	25000
<b>DR420/450</b>	Brother HL2230/2240/2270	12000
<b>DR720</b>	Brother HL5440D/5450D/5470D/5470DWT/6180DW/6180DW T/MFC8710DW/MFC8790DW	30000
<b>DR-6000/DR400</b>	BROTHER HL1030/1230/1240/1250/1270N/1435/1430/1440/145 0/1470N; DCP1200/1400;INTELLIFAX 4100/4750/14750E/5750/5750E; MFC8300/8500/8600/8700/9600/9700/9800/P2500/96 50/9870/9660/9750/9850/9880/9860/9760; FAX8350/8370/8750HL1650/1650N/1650NPlus/1670 N/1850/1870N/5040/ 5050/5050LT/5070N/5140/5150D/5150DLT/5170D/51 70DNLT; DCP8040/8045D/8020/8025D; MFC8420/8820D/8820DNS/8220/8440/8640D/8840D/ 8840DN	20000
<b>TN221/241/281BK</b>	Brother	2500
<b>TN221/225/241/245/ 281/285C</b>	HL3140CW/3170CDW/MFC9130DCN/CFC9330CDW /MFC-9340CDW	1400
<b>TN221/225/241/245/ 281/285M</b>		1400
<b>TN221/225/241/245/ 281/285Y</b>		1400
<b>TN221/241/281BK</b>	Brother	2500
<b>TN221/225/241/245/ 281/285C</b>	HL3140CW/3170CDW/MFC9130DCN/CFC9330CDW /MFC-9340CDW	2200
<b>TN221/225/241/245/ 281/285M</b>		2200
<b>TN221/225/241/245/ 281/285Y</b>		2200
<b>TN321/331BK</b>		2500
<b>TN321/331C</b>	Brother HL-	1500
<b>TN321/331M</b>	8250CDN/8350CDW/DCP-	1500
<b>TN321/331Y</b>	L8400DN/L8450CDW/MFC-8650CDW/8850CDW	1500
<b>TN326/336BK</b>		4000
<b>TN326/336C</b>		3500
<b>TN326/336M</b>		3500
<b>TN326/336Y</b>		3500
<b>TN-04BK</b>		10000
<b>TN-04C</b>		6600
<b>TN-04M</b>	BROTHER HL2700CN/MFC-9420	6600
<b>TN-04Y</b>		6600
<b>TN210/230/240BK</b>		2200
<b>TN210/230/240C</b>		1400
<b>TN210/230/240M</b>	BROTHER HL3040CN/3070CN, MFC9010CN	1400
<b>TN210/230/240Y</b>		1400
<b>TN310/320 BK</b>		2500
<b>TN310/320 C</b>	BROTHER HL1150DN/HL11570DN/MFC9140CDN/9560CDW/907	1500

<b>TN310/320 M</b>	HL4150DN/HL4570DN/MFC9460CDN/9560CDW/9970CDW	1500
<b>TN310/320 Y</b>		1500
<b>TN315/325/345/348 BK</b>		6000
<b>TN315/325/345/348 C</b>	BROTHER	3500
<b>TN315/325/345/348 M</b>	HL4150DN/HL4570DN/MFC9460CDN/9560CDW/9970CDW	3500
<b>TN315/325/345/348 Y</b>		3500
<b>TN115B</b>		5000
<b>TN115C</b>		4000
<b>TN115M</b>	BROTHER HL4040/4050/4070, MFC9040/9440/9840	4000
<b>TN115Y</b>		4000
<b>FOR USE IN PANASONIC</b>		
<b>UG-3313</b>	PANASONIC UF-550/560/770/880	9500
<b>UG-3350</b>	PANASONIC UF-585/595	7500
<b>76A</b>	PANASONIC KX-F501/502//503/523; M551/M552/M553/MB751/752/753	2000
<b>FAT92A</b>	PANASONIC KX-MB781	2000
<b>-KX-FAT407</b>	PANASONIC KX-MB1500/1520	2500
<b>-KX-FAD78A Drum Unit</b>	PANASONIC KX-FL501/502/503/KX-FLM551/M552/M553/KX-FLB751/B752/B753	10000
<b>-KX-FAD297 Drum Unit</b>	PANASONIC KX-FL421/422/423/323/328	10000
<b>-KX-FAD296 Toner Unit</b>	PANASONIC KX-FL421/422/423/323/328	1400
<b>-KX-FAD89E Drum Unit</b>	PANASONIC KX-FL401/402/403/411/412/413	10000
<b>-KX-FAD88E Toner Unit</b>	PANASONIC KX-FL401/402/403/411/412/413	1400
<b>-KX-86E Drum Unit</b>	PANASONIC KX-FLB803/813/823	10000
<b>-KX-85E Toner Unit</b>	PANASONIC KX-FLB803/813/823	5000
<b>-KX-FA84E Drum Unit</b>	PANASONIC FLM668/653CN/KX-513/543/613	10000
<b>-KX-FA83E Toner Unit</b>	PANASONIC FLM668/653CN/KX-513/543/613	2500
<b>KX-FAD93A Drum Unit</b>	PANASONIC KX-MB262/263/271/763/772/773/781/78	6000
<b>-KX-FAD412 Drum Unit</b>	PANASONIC KX-MB2000RU/2020	10000
<b>-KX-FAD411 Toner Unit</b>	PANASONIC KX-MB2000RU/2020	1400
<b>FOR UES IN LEXMARK</b>		
<b>20K1400 C</b>		6000
<b>20K1401 M</b>	Lexmark C510	6000
<b>20K1402 Y</b>		6000
<b>20K1403 Bk</b>		10000
<b>MS310/410/510/610</b>	Lexmark MS310d/MS310dn/MS410d/MS410dn/MS510dn/MS610DN/MS610DTN/MS610DE/MS610DTE	1500 5000
<b>MS410/510/610</b>	Lexmark MS410d/MS410dn/MS510dn/MS610DN/MS610DTN/MS610DE/MS610DTE	10000
<b>MS510/610</b>	Lexmark MS510dn/MS610DN/MS610DTN/MS610DE/MS610DTE	20000 2500
<b>MX310/410/510/511/610/611</b>	Lexmark MX310dn/MX410de/MX511dte/MX511dhe/MX511de/MX510de /MX610dw/MX611de/MX611dhe/MX611dte	10000
<b>MX510/511/610/611</b>	Lexmark MX511dte/MX511dhe/MX511de/MX510de /MX610dw/MX611de/MX611dhe/MX611dte	20000
<b>MS710/810</b>	Lexmark MS710/810	8000
<b>MS710/810</b>	Lexmark MS710/810	25000
<b>MS710/810</b>	Lexmark MS710/810	45000
<b>MS812</b>	Lexmark MS812	45000
<b>E120</b>	Lexmark E120	2500
<b>E210</b>	Lexmark ORA E210	2000
<b>E230/232</b>	Lexmark E230/232/E234/E238/E240/E242/E330/E340/E332/E342	2500
<b>E330/340</b>	Lexmark E330/E340/E332/E342	6000
<b>E310</b>	Lexmark ORA E310	6000
<b>X215</b>	Lexmark X215	2500
<b>X340/342</b>	Lexmark X340N/X342N	3000

X342	Lexmark X342N	6000
X264/363/364	Lexmark X264DN/X363DN/X364DN	3500
X264/363/364	Lexmark X264DN/X363DN/X364DN	9000
X203/X204	Lexmark X203NN	2500
E250/E350D	Lexmark E250D/350D	3500
E350/351/352D	Lexmark E350D/351/352D	6000
E350/351/352D	Lexmark E350D/351/352D	9000
E450	Lexmark E450/450DN	6000
E450	Lexmark E450/450DN	11000
E320	Lexmark E320	3000
E321	Lexmark E321	6000
E260/360/460	Lexmark E260	3500
E360/460	Lexmark E360/460	9000
E460	Lexmark E460	15000
520/522	Lexmark T520/522/520N/522N	21000
520/522	Lexmark T520/522/520N/522N	21000
610/612	Lexmark T610/612/614/616	21000
610/612	Lexmark T610/612/614/616	21000
620/622	Lexmark T620/622 IBM1130/1140	32000
620/622	Lexmark T620/622 IBM1130/1140	32000
630/632	Lexmark T630/632/640/642 IBM1332/1352/1372	32000
630/632	Lexmark T630/632/640/642 IBM1332/1352/1372	32000
640/642	Lexmark T640/642/644 IBM 1532/1552/1572	21000
640/642	Lexmark T640/642/644 IBM 1532/1552/1572	21000
T650	LEXMARK T650N	7000
T650	LEXMARK T650N	25000
E120 Drum	LEXMARK E120	25000
E230 Drum	Lexmark E230/232/234/238/240/330/340/332/342/DELL1710/1700/IBM142	30000
E260/360/460 Drum unit	Lexmark E260/360/460	30000
E250D/E350D Drum	Lexmark E250D/350D	30000
<b>FOR USE IN XEROX</b>		
CT201114	Xerox Docuprint C1110/1110B	2000
CT201115		1000
CT201117		1000
CT201116		1000
106R01274	Xerox Phaser 6110/6110MFP	2000
106R01271		1000
106R01273		1000
106R01272		1000
106R00671	Xerox Phaser 6250	4000
106R00668		4000
106R00670		4000
106R00669		4000
106R01334	Xerox Phaser 6125MFP/6130/C6140	2000
106R01331		1000
106R01333		1000
106R01332		1000
106R01455	Xerox Phaser 6128	3100
106R01452		2500
106R01453		2500
106R01454		2500
113R00722		3000
113R00719		2000

113R00720	Xerox 180	2000
113R00721		2000
113R00726		8000
113R00723	Xerox6180	6000
113R00724		6000
113R00725		6000
106R01391		3000
106R01388	Xerox6280	2200
106R01389		2200
106R01390		2200
106R01395		7000
106R01392	Xerox6280	5900
106R01393		5900
106R01394		5900
106R01281		2500
106R01278	Xerox Phaser 6130	1600
106R01279		1600
106R01280		1600
106R01479		2000
106R01477	Xerox Phaser 6140	2000
106R01478		2000
106R01480		2600
106R01649		2600
106R01466	Xerox 6121MFP	2600
106R01468		2600
106R01467		2600
106R01634/106R01627 (注意代码区分)		2200
106R01631/106R01628	Xerox 6010/6000	1400
106R01633/106R01629 CP105		1400
106R01632/106R01630		1400
CT201591		2000
CT201592	Xerox DOCUPRINT	1400
CT201593	CP105B/CP205/CP205W/CM205B	1400
CT201594		1400
CT201632		3000
CT201633	Xerox DocuPrint CM305D/CM305DF/CP305D	3000
CT201634		3000
CT201635		3000
106R01597/ 106R01604(注意代码区分)		3000
106R01594/106R01601	Xerox Phaser 6500/Workcenter 6505	2500
106R01595/106R01602		2500
106R01596/106R01603		2500
106R00680		5000
106R00681	Xerox PHASER 6100	5000
106R00682		5000
106R00684		7000
CT201948/CT201950	Xerox DccuPrint P455d	10000
CT201949/CT201951		25000
CT201937/CT201939	FujiXerox DocuPrint P355d DocuPrint p355d	4000
CT201938/CT201940	b/DocuPrint M355df	10000

106R02307/3320		11000
106R02304/3320	Xerox Phaser 3320	5000
106R02306/3320		11000
106R02309/3315		2300
106R02311/3315	Xerox Workcentre 3315	5000
106R02300/3315		2300
106R02310/3315		5000
106R02311/3325		5000
106R02313/3325	Xerox Workcentre3325	11000
106R02310/3325		5000
106R02312/3325		11000
CT201918	Xerox DocuPrint P255/M255	2500
106R02773	XEROX WorkCentre 3020/3025	1500
106R02775		1500
106R02777	Xerox WorkCentre 3215/3225/3260/3052	3000
106R02778		3000
101R00474 Drum		10000
CT201613	Xerox DOCUPRINT P105B/P205B	2200
006R01179	Xerox WorkCentre M118/118i/Cepycentre C118	11000
CT200401	Xerox DocuCentre 156/186/1085/1055	9000
CT201795	Xerox DocuCentre-IV2056/2058	9000
006R01159		
006R01160	Xerox WorkCentre 5325/5330/5335	30000
006R01184	Xerox WorkCentre PRO 128/133/123/ M128/123/133	30000
006R01182	Xerox WorkCentre PRO 128/133/123/ M128/123/133	30000
CT200417	Xerox DocuCentre 286/136/336/2005/2055/3005	30000
CT350268	XEROX DOCUPRINT 240A/340A	10000
CT350269	XEROX DOCUPRINT 340A	17000
CWAA0649	XEROX DOCUPRINT 203A/204A	2500
CWAA0648 Drum Unit	XEROX DOCUPRINT 203A/204A	12000
CT201734	Xerox DocuCentreIV 2060/3060/3065	25000
106R01305	Xerox WorkCentre™ 5225/5230/5222	30000
113R00668	Xerox phaser 5500	30000
106R01294	Xerox phaser 5550	35000
CT201911	Xerox Docucentre S1810/2010	15000
013R22589 Drum Unit	Xerox CopyCentre C123/C128/C118/ WorkCentre M118/M118i/M123/M128/133/ WorkCentre Pro 123/128/ 133 CopyCentre 133/	60000
106R02183	XEROX PHASER 3010/3040/Workcentre3045	2300
106R01378		2200
106R01379	Xerox Phaser 3100MFP	4000
CT350285 Drum Unit	Xerox DocuCentre 156/186/1085/1055	55000
CT350299 Drum Unit	Xerox DocuCentre 286/136/336/2005/2055/3005	65000
101R00435 Drum Unit	Xerox WorkCentre™ 5225/5230/5222	60000
113R00670 Drum Unit	Xerox phaser 5500/5550	60000
006R60387	Xerox Vivace 228/230/250/258/288/ 330/338/340/388/5816/5821/5825/5834	7000
006R01017	Xerox Vivace 2015/2018	7000
006R01020	Xerox Vivace 5915/5918/5921	6000

006R01046	Xerox WorkCentre™ Pro 245/255/45/232/238/55/35 WorkCentre M35™/45™/55™, WorkCentre 5645/5655/5632/5638  WorkCentre 5735/5740/5745/5755/232/238/245/255 CopyCentre232/238/245/255 CopyCentre C55™/35™/45™ Digital Copier	30000
006R01044	Xerox WorkCentre 415/518/520/Pro 315/320/420	6000
CT201052	Xerox Docucentre 1080/2000/2003	6000
106R01277	Xerox WorkCentre 5020/5016	5000
106R00584	Xerox WorkCentre M15/PRO412/F12/312	6000
113R00663 Drum Unit		15000
006R01278	Xerox WorkCentre™ 4118/FaxCentre™ 2218	8000
113R00671	WorkCentre/4118/M20/20i/CopyCentre C20/ FaxCentre 2218	20000
113R00656	Xerox Phaser 4500	10000
113R00657		18000
103R00711	Xerox Phaser 4510	10000
103R00712		19000
113R00737	Xerox Phaser 5335	10000
113R00730	XEROX PHASER 3200MFP	3000
108r00908	XEROX PHASER 3140	1500
108R00909		2500
106R01373	XEROX PHASER 3250	3500
106R01374		5000
106R01411	XEROX PHASER 3300	4000
106R01412		8000
106R01033	Xerox Phaser 3420/3425	5000
106R01034		10000
106R01485	XEROX Workcentre 3210/3220	2000
106R01486		4100
113R00296	XEROX P8E/P8EX/385/390	6000
106R01047	XEROX WorkcentreC20/M20/M20I	8000
109R00639	XEROX 3110/3210	3000
106R00687	Xerox Phase 3450	5000
106R00688		10000
106R01245	Xerox Phaser 3428D/3428DN	4000
106R01246		8000
106R01414	Xerox Phaser 3435/3435N/3435DN	4000
106R01415		10000
109R00725	XEROX 3130/3115/3121/3120/PE16	3000
106R01159	Xerox Phaser-3117/3122/3124/3125	3000
013R00625	XEROX 3119	3000
113R00667	XEROX Workcentre PE16	3500
PE114	Xerox PE114E	3000
PE120	XEROX PE120/120I	5000
PE220	XEROX PE220	3000
108R00795	XEROX Phaser 3635MFP	10000
106R01528	XEROX WorkCentre 3550	5000
106R01530		11000
106R01148	Xerox Phaser 3500	6000
106R01149		12000
106R1370	Xerox Phaser 3600	7000
106R1371		14000
<b>FOR USE IN DELL</b>		
310-6640	DELL 1100	3000
310-3545	DELL P1500	6000
310-5416	DELL 1600N	3000
310-5417	DELL 1600N	5000
310-7020	DELL 1700	3000



310-7020	DELL 1700	6000
310-8706	DELL 1720	3000
310-8706	DELL 1720	6000
330-4131	DELL 2330D	2000
330-4131	DELL 2330D	6000
330-2208	DELL 2335	2000
330-2209	DELL 2335 芯片价格	6000
310-7945	DELL 1815	5000
330-9524	Dell1130/1133/1133n/1135	1500
330-9523	Dell1130/1133/1133n/1135	2500
330-2044	DELL5330	10000
330-2045	DELL5330	20000
330-3012BK		1500
330-3015C	DELL1230/1235C	1000
330-3014M		1000
330-3013Y		1000
310-9059		1000
310-9061	DELL1320	1000
310-9063		1000
310-9065		1000
310-9058		2000
310-9060	DELL1320	2000
310-9062		2000
310-9064		2000
K310-5726		4000
C310-5731	DELL 3100CN	4000
M310-5730		4000
Y310-5729		4000
341-3568Bk		2000
341-3569Y	DELL 3010CN	2000
341-3570M		2000
341-3571C		2000
310-8093Bk		5000
310-8095C	DELL 3110 / 3115CN	4000
310-8097M		4000
310-8099Y		4000
310-8092Bk		8000
310-8094C	DELL 3110 / 3115CN	8000
310-8096M		8000
310-8098Y		8000
310-5807Bk		9000
310-5808Y	DELL 5100CN	8000
310-5809M		8000
310-5810C		8000
310-7890Bk		9000
310-7892C	DELL 5110CN	8000
310-7894M		8000
310-7896Y		8000
<b>FOR USE IN OKI</b>		
O42804501	OKI C5100N/5200/5400DN/5100/5400N/5400/5300N/	3000
O42804502	5200N/5400DTN/5300DN/5400TN/3200N/5400DTN/	3000
O42804503		3000
O42804504	3200/5400TN/5200/5400DN/5400N/5400/5200N/ 3100/5250/5250N/5510MFP/5450N/5250DN/ 5540MFP/5450DN/3200N/32	3000

<b>O42127401</b>	OKI C5100N/5200/5400DN/5100/5400N/5400/5300N/	5000
<b>O42127402</b>	5200N/5400DTN/5300DN/5400TN/3200N/5400DTN/	5000
<b>O42127403</b>	3200/5400TN/5200/5400DN/5400N/5400/5200N/	5000
<b>O42127404</b>	3100/5250/5250N/5510MFP/5450N/5250DN/ 5540MFP/5450DN/3200N/32	5000
<b>43459405</b>		2500
<b>43459406</b>		2500
<b>43459407</b>	OKI C3300/3400	2500
<b>43459408</b>		2500
<b>O43381909</b>		2000
<b>O43324445</b>		2000
<b>O43381910</b>	<b>O43324446</b>	2000
<b>O43381911</b>	OKI C5600/C5700	2000
<b>O43324447</b>		6000
<b>O43324412</b>		
<b>O43384448</b>		
<b>O44324426</b>	<b>O43324421</b>	5000
<b>O44324427</b>	<b>O43324422</b>	5000
<b>O44324426</b>	<b>O43324423</b>	5000
<b>O44324425</b>	<b>O43324424</b>	6000
<b>O44250708</b>		2500
<b>O44250707</b>	OKI C110/130	2500
<b>O44250706</b>		2500
<b>O44250705</b>		2500
<b>B44318608 BK</b>		11000
<b>B44318607 C</b>		11500
<b>B44318606 M</b>	OKI C710/711	11500
<b>B44318605 Y</b>		11500
<b>44469803</b>		3500
<b>44469706</b>		2000
<b>44469705</b>	OKI C310/330/510/530	2000
<b>44469704</b>		2000
<b>44469804</b>		5000
<b>44469724</b>		5000
<b>44469723</b>	OKI C510/530	5000
<b>44469722</b>		5000
<b>44992401</b>	OKI B401/MB441/MB451/MB451W	1500
<b>44992402</b>	OKI B401/MB441/MB451/MB451W	2500
<b>B411</b>	OKIDATA B411	4000
<b>B431</b>	OKIDATA B431	4000
<b>B431</b>	OKIDATA B431	10000
<b>B431</b>	OKIDATA B431	12000
<b>B410</b>	OKIDATA B410/430/440	3500
<b>B430 Toner</b>	OKIDATA B430/440	7000
<b>B440 Toner</b>	OKIDATA B440	10000
<b>B440 Toner</b>	OKIDATA B440	12000
<b>B2200/2400</b>	OKIDATAB2200/2400	2000
<b>B4400 Toner</b>	OKIDATA B4400	3000
<b>B4600 Toner</b>	OKIDATA B4600	7000
<b>B4100/4200/4300</b>	OKIDATA B4100/4200/4250/4300/4350	2500
<b>B4200/4300</b>	OKIDATA B4300/4350	6000
<b>B410/430 Drum Unit</b>	OKIDATA B410/430/440	25000
<b>B4100/4200/4300 DRUM UNIT</b>	OKIDATA B4100/4200/4250/4300/4350	25000

<b>B4400/4600 DRUM UNIT</b>	OKIDATA B4600/B4600N	25000
<b>FOR USE IN RICOH</b>		
<b>104</b>	RICOH AC104	3000
<b>SP1000</b>	RICOH SP1000	4000
<b>SP100</b>	RICOH Aficio SP100	2000
<b>SP111</b>	RICOH Aficio SP111	2000
<b>SP200</b>	RICOH Aficio SP200	2600
<b>SP310</b>	RICOH Aficio SP310	6400
<b>SP310</b>	RICOH Aficio SP310	3500
<b>SP3400/3410/3500/3510</b>	RICOH Aficio	2500
	SP3400/3410/3500SF/3510SF/3500DN/3510DN	5000
		6400
<b>4000L</b>	RICOH 4000L	6000
<b>FOR USE IN KYOCERA</b>		
<b>TK-17</b>	PRINTER FS-1000/1010/1020D/1050/118MFP/KM-1500	6000
<b>TK-18</b>	PRINTER FS-1000/1010/1020D/1050/118MFP/KM-1500	7200
<b>TK-100</b>	PRINTER FS-1000/1010/1020D/1050/118MFP/KM-1500	7200
<b>TK-110/111/112/113</b>	PRINTER FS-720/820/920/1116MFP	7200
<b>TK-120/122</b>	PRINTER FS-1030D	7200
<b>TK-130/131/132/133/134</b>	PRINTER FS-1300D/1350DN/1128MFP	7200
<b>TK-140/142/144</b>	PRINTER FS-1100	4000
<b>TK-137</b>	KM2810/2810DP/2820	7200
<b>TK-160/161/162/164</b>	PRINTER FS-1120D	2500
<b>TK-170/171/172/174</b>	PRINTER FS-1320D/1370DN	7200
<b>TK-310/312</b>	PRINTER FS-2000D	12000
<b>TK-320/322</b>	PRINTER FS-3900DN	15000
<b>TK-330/332</b>	PRINTER FS-4000DN	20000
<b>TK-340/341/342/343/344</b>	PRINTER FS-2020D	12000
<b>TK-350/351/352/354</b>	PRINTER FS-3920DN/3925DN	15000
<b>TK-360/361/362/364</b>	PRINTER FS-4020D	20000
<b>TK-440/441</b>	PRINTER FS-6950DN	15000
<b>TK-450/451/452/454</b>	PRINTER FS-6970DN	15000
<b>TK-50</b>	PRINTER FS-1900	15000
<b>TK-55/57</b>	PRINTER FS-1920	15000
<b>TK-60</b>	PRINTER FS-1800/3800	20000
<b>TK-65/67</b>	PRINTER FS3820N/3830N	20000
<b>TK-70/76</b>	PRINTER FS-9100/9500/9520DN/9120DN	40000
<b>TK-710/712</b>	PRINTER FS-9530DN	40000
<b>TK-1103-AS</b>	KYO FS1110/1024/1124 chip-AS	2100
<b>TK-1100-EU</b>	KYO FS1110/1024/1124 chip-EU	2100
<b>TK-1102-US</b>	KYO FS1110/1024/1124 chip-US	2100
<b>TK-1104-AU</b>	KYO FS1110/1024/1124 chip-AU	2100
<b>TK-1130-EU</b>	KYO FS1030/1130 chip-EU	3000
<b>TK-1132-US</b>	KYO FS1030/1130 chip-US	3000
<b>TK-1133-AS</b>	KYO FS1030/1130 chip-AS	3000
<b>TK-1134-AU</b>	KYO FS1030/1130 chip-AU	3000
<b>TK-1140-EU</b>	KYO FS1035/1135/M2035DN/M2535DN chip-EU	7200
<b>TK-1142-US</b>	KYO FS1035/1135 chip-US	7200
<b>TK-1143-AS</b>	KYO FS1035/1135 chip-AS	7200
<b>TK-1144-AU</b>	KYO FS1035/1135 chip-AU	7200
<b>TK1110</b>		2500
<b>TK1112</b>	KYOCERA FS1040/1120MFP/1020MFP	2500
<b>TK1113</b>		2500
<b>TK1114</b>	KYOCERA FS1041/1120MFP/1020MFP	2500
<b>TK1115</b>	KYOCERA FS1041/1220MFP/1320MFP	2500
<b>TK1119</b>	KYOCERA FS1041/1320MFP	2500
<b>TK1120</b>		3000

TK1122		3000
TK1123	KYOCERA FS1060DN/1125MFP/1025MFP	3000
TK1124		3000
TK1125		3000
TK1129	KYOCERA FS1061DN/1325MFP	3000
TK3100	KYOCERA FS2100D/2100DN	12500
TK3102		12500
TK3103	KYOCERA FS2100D	12500
TK3104	KYOCERA FS2100D/2100DN	12500
TK3110		15500
TK3112		15500
TK3113	KYOCERA FS4100DN	15500
TK3114		15500
TK3120		21000
TK3122		21000
TK3123	KYOCERA FS4200DN	21000
TK3124		21000
TK3130	KYOCERA FS4200DN/4300DN	25000
TK3132	KYOCERA FS4300DN	25000
TK3133	KYOCERA FS4300DN	25000
TK3134	KYOCERA FS4200DN/4300DN	25000
TK-540/541/542/543/544	PRINTER FS-C5100DN	C.M.Y:4000 K:5000
TK-550/551/552/554	PRINTER FS-C5200DN	C.M.Y:6000 K:7000
TK-560/561/562/564	PRINTER FS-C5300/C5305DN	C.M.Y:10000 K:12000
TK-570/571/572/574	PRINTER FS-C5400DN	C.M.Y:10000 K:16000
TK-590/591/592/594	PRINTER FS-C2026/C2126MFP	C.M.Y:5000 K:7000
TK-880/882	PRINTER Taskaifa FS-8500DN	C.M.Y:18000 K:25000
TK-410/411/420/421/418/428/438	COPIER KM-1620/1635/1650/2035/2050/2550	15000
TK-435/437/439/458/448	COPIER Taskaifa 180/181/220/221	15000
KM-1525/1530	COPIER KM-1525/1530/2030	10000
TK-675/679/678	COPIER KM-2540/2560/3040/3060/Taskaifa 300i	20000
TK-715/717/718	COPIER KM-3050/4050/5050/420i/520i	34000
TK-725	COPIER Taskaifa 420i/520i	34000
KM- 2530/3035	COPIER KM-2530/3035/4035/5035	34000
TK-601/603	COPIER KM-4530/5530/6330/7530	30000

toner kodu	printer	toz gramaj
<b>FOR USE IN SHARP</b>		
AR-168	COPIER AR-121/156/152/158	238g
AR-153	COPIER AR-121/156/152/158	238g
AR-016	COPIER AR-5316/5318/5320	500g
AR-202	COPIER AR-162	500g
AR-270	COPIER ARM-235/255/275	500g
AR-310	COPIER AR-235/275/237/5127	500g
AR-311	COPIER ARM-236/256/258/276	500g
AR-021	COPIER AR-3818/3020D	500g
AR-020	COPIER AR-3818/3020D	500g
MX-312	COPIER Monochrome MFP MX-M261/ M261N / 311 / M311N	428g
AL-100	COPIER AL1000/1010/1014/1200/1220/1250/ 1520/1521/1630/ 1641/1651	
MX-500	COPIER MZ-283/363/453/500/503	930g
MX-235	COPIER AR-5618/5620/5623	500g
<b>FOR USE IN TOSHIBA</b>		
T-1640	COPIER E-163/165/203/167/207	190g
T-1640	COPIER E-163/165/203/167/207	300g
T-1640	COPIER E-163/165/203/167/207	675g
T-2320	COPIER E-230/280	675g
T-2340	COPIER E-232/282	675g
T-3520	COPIER E-350/450/352/452	675g
T-1810	COPIER E-181/182/212/242	675g
T-1810	COPIER E-181/182/212/242	177g
T-1810	COPIER E-181/182/212/242	290g
T-4530	COPIER E- 255/305/305S/305SD/355/355S/ 355SD/455/455S/ 455SD	290g
T-4530	COPIER E- 255/305/305S/305SD/355/355S/ 355SD/455/455S/ 455SD	675g
T-1200	COPIER E-120/150	238g
T-6000	COPIER E- 520/600/720/850/555/655/755/855	900g
T-6510	COPIER E-550/650/810	<b>900g</b>
T-2450	COPIER E-STUDIO 223/225/243/245	134g
T-1800	COPIER E-STUDIO 18	187g
<b>FOR USE IN XEROX</b>		
420	COPIER 415/518/520/250/315/320/420	260g
1080	COPIER 1080/2000/2003	260g
5020/5016	COPIER 5016/5020	260g
156/186	COPIER 156/186/1055/1085	230g
236/286	COPIER 236/286/336/2005/3005/2007/3007	680g
XD100TD	COPIER XD100/102/103F/105F/120F/125F/130DF/155DF	

DC450	COPIER DC-450/360/250/2200/3300/4300	C.M.Y:400g/K:600g
DC-5065	COPIER DC-5065/6500/5400/7500/6075/5540/5400/7550	CMYK:750g
DC1810	COPIER S1810/S2010	230g
DC2060	COPIER 2060/3060/3065	680g
DC2056	COPIER 2056/2058	230g
<b>FOR USE IN CANON</b>		
NPG-20/GPR-8/C-EXV-5	COPIER iR-1600/2000	440g
NPG-28/C-EXV14/GPR-18	COPIER iR-2016/2020	460g
NPG-21/GPR-10/C-EXV7	COPIER IR-1210/1230/1270/1510/1570/1300/1310/1630/1670	280g
NPG-32/GPR-22/C-EXV18	COPIER iR-1018/1022	465g
NPG-54/GPR-38/C-EXV36	COPIER IR-6065/6055/6075/6255/6265/6275	2200g
NPG-25/GPR-15/C-EXV11	COPIER iR-501K/728K/2230/2270/2830/2870/3025/3030/ iR3225/3230	1060g
NPPG-26/GPR-16/C-EXV-12	COPIER iR502K/503K/735K/iR3035/3045/3235/3245 iR-3530/3570/4530/4570/LBP4500	1219g
NPG-27/GPR-17/C-EXV13	COPIER iR-5570/6570	2000g
NPG-29/GPR-19/C-EXV15	COPIER iR-7105/7086	2000g
NPG-36/GPR-24/C-EXV-22	COPIER iR-5055/5065/5075	2200g
NPG-18/GPR-6/C-EXV-3	COPIER IR-2200/2800/3300	795g
GP-605/GPR-1/GPR-7	COPIER GP-550/558/600/605/iR-8500	1260g
NPG-50/GPR-34/C-EXV32	COPIER Monochrome MFP IR2535i / IR2545i	925g
NPG-51/GPR-35/C-EXV33	COPIER Monochrome MFP IR2520i/2525i /2525/2530i	700g
NPG-53/GPR-37/C-EXV35	COPIER IR-8085/8095/8105/8285/8205/8295	2200g
NPG-56/GPR-42/C-EXV38	COPIER IR 4045/4051	
NPG-57/GPR-43/C-EXV39	COPIER IR 4025/4035	
NPG-35/GPR-23/C-EXV21	COPIER Color MFP IR-C2880i/3080i/3580i /2550i/3380i	C.M,Y: 260g/K:575g
NPG-52 / GPR-36/ C-EXV34	COPIER Color MFP IR-AC2020i / 2025i / 2030i /C2225/C2230	C.M,Y: 270g/K:420g
NPG-45/GPR-30/C-EXV28	COPIER Color MFP IR-AC5045i/5051/5250/5255	Y: 747/C.M:600 /K:900g
NPG-46/GPR-31/C-EXV29	COPIER Color MFP IR-AC 5030/5035/C5235/C5240	C.M,Y: 500g/K:900g
<b>FOR USE IN RICOH</b>		
1220D	COPIER 1015/1113/115P	260g
1230/1610	COPIER MP1610/2015/2018/2000/2020	185g
1270D	COPIER 1515/1515MF	220g
2210D	COPIER 220/270	360g
2500D	COPIER MP2500/MP2500LN	360g
3205D	COPIER 1035/1045	550g

3210D	COPIER 2035E/2045E/3035/3045/3035PS/304 5PS	550g
4500D	COPIER MP4000B/4000BSP/5000B/5000BSP	1000g
5200D	COPIER A550/650	1219g
5305D	COPIER 551/1055	1219g
6210D	COPIER 1060/1075/2051/2060/2075	1219g
8205D	COPIER A1085/2090	1460g
2220D	COPIER MP2550B/MP3350B/3025/3030	360g
8135D	COPIER AFICIO 1350	1650g
MPC2500C/3000C	COPIER Aficio MPC 2000/2500/3000/2525/3030	B:450g/C.M.Y:360g
MPC2550	COPIER Aficio MPC 2030/C2530/C2050/C2550	B:215g/C.M.Y:135g
MPC3300	COPIER Aficio MPC 2800/C3300	B:450g/C.M.Y:360g
MPC4500C	COPIER Aficio MPC 3500/C4500	B:510g/C.M.Y:400g
MPC5000C	COPIER Aficio MPC 4000/C5000	B:510g/C.M.Y:400g
SP C811DN	COPIER Aficio SPC810/811	B:450g/C.M.Y:360g
SP C821DN	COPIER Aficio SPC820/821	B:450g/C.M.Y:360g
<b>FOR USE IN KONICA MINOLTA</b>		
104A/B	COPIER MT1054/1085/1084	270g
106A/B	COPIER Digital Dil 152/183/183s/161/2011	413g
204A/B	COPIER MT 2030/3000/3010	420g
TN-211	COPIER Bizhub 250	360g
TN-311	COPIER Bizhub 350	360g
TN-114	COPIER 162/210	410g
TN-115	COPIER 163V/7616V	410g
TN-117H	COPIER BIZHUB-164/184/7718	285g
TN-511	COPIER Monochrome Copier BIZHUB 420/500/421/501	676g
TN-217	COPIER Monochrome Copier BIZHUB 223 / 283 / 7828	360g
TN-414	COPIER Monochrome Copier BIZHUB 363/423	512g
TN-415	COPIER BIZHUB 36/42	512g
TN-214	COPIER Bizhub C200	C.M.Y:364g/K:466g
TN-310	COPIER Color Copier BIZHUB C350/351/450	C.M.Y.K:230g
TN-216	COPIER BIZHUB C220/C280	C,M,Y:400g/K:450g
TN-319	COPIER BIZHUB C360	C,M,Y:400g/K:450g
TNP-22	COPIER Color Printer BIZHUB C35	C:105g/M:128g/Y:148g/ K:136g
TNP-27	COPIER Color Printer BIZHUBC25	C:105g/M:128g/Y:148g/ K:136g
TNP-18	COPIER color Printer 4570EN/4570DN	C:105g/M:128g/Y:148g/ K:136g
TN-321	COPIER BIZHUBC224/C364	C,M,Y:400g/K:450g
TN-512	COPIER BIZHUBC454/C554	C,M,Y:400g/K:450g